

Warning Signs and Barricades

WAC 296-878-160

Rule

WAC 296-878-16005

Provide warning signs and barricades when suspended equipment is used

You must

- (1) Place warning signs below suspended equipment
- (2) Block the ground area with barricades directly under or next to the work zone
- (3) Assign a **competent person** to decide if additional protection is necessary
- (4) Make sure all tools used by the worker are attached to the worker, seatboard, or boatswain's chair



Reference:

Rules for protecting workers from overhead hazards are listed in WAC 296-800-16055, Make Sure Your Employees Use Appropriate Head Protection.

Warning Signs
and Barricades

